

## SP Samonavíjecí zachycovač pádu

## SP Selfretracting Lifeline SP SRL, SP SRLD – max.weight 150kg

SKYPRO s.r.o.

phone No.: +31 (0)6 83905868

1. máje 56

e-mail: [info@skyprosro.cz](mailto:info@skyprosro.cz)

54901 Nove Mesto nad Metuji

web: [www.skyprosro.cz](http://www.skyprosro.cz)

Czech Republic

je certifikována notifikovanou osobou CE1019 /

EN 360:2002, EN 365:2004

certified by CE1019

Výrobek / Product	SP Selfretracting Lifeline
Model / Model	SP SRL
Produktové číslo / Article number	SP-SRL-2.0

.....  
razítko a podpis / stamp and signature

### Instruction manual for SP Selfretracting Lifeline ( max.weight 150kg )

Types : SP SRL, SP SRLD

EN 360:2002 EN365:2004

CE1019

#### DESCRIPTION:

SP SRL, SP SRLD selfretracting fall arrester devices are intended to be used as a part of a personal fall arrest system. Applications for these products include inspection work, construction and demolition, maintenance, oil production, confined space rescue and similar activities

**WARNING:** Following any fall incident and arrest (even a light one), your SP SRL, SP SRLD selfretracting fall arrester devices must be withdrawn from use.

#### LABELLING:

SP SRL, SP SRLD selfretracting fall arrester devices are identified by labelling as required by EN 365 standards with information about manufacturer, model of lanyard, MFG year where there exists the possibility of a fall from height. This equipment is specially designed to dissipate fall energy and limit fall arrest forces transferred to the body. When properly used, SP SRL, SP SRLD selfretracting fall arrester devices can reduce the impact energy generated during a fall to less than 4kN. This product type SP SRLD, SP SRL can be used by maximal user weight of 150kg.

#### BASIC EQUIPMENT:

SP SRL, SP SRLD selfretracting fall arrester devices are manufactured from the highest quality materials and undergo through testing and inspection in accordance with a strict quality control program. SP SRL, SP SRLD selfretracting fall arrester devices may be constructed of one or a combination of the following materials:

Webbing: 17mm Aramid/PES

Threads: PA

Connectors: forged steel, zinc plated

Shock absorber: 32mm PA webbing, 25mm PES webbing, PA threads

#### FITTING:

- Before use of this equipment, carefully inspect it to assure that it is in a good working condition. Check for wrong or damaged parts. Ensure all hardware is present and secure, and is not distorted or have any sharp edges, burrs, cracks, or corrosion. Ensure self locking snap hooks or carabiners work properly. Inspect webbing for wear, cuts, burns, frayed edges, breaks, or other damage.

- Select a rigid anchorage point that is capable of supporting the required loads. The anchorage location must be carefully selected to reduce possible free fall and swing fall hazards and to avoid striking an object during a fall. The anchorage should be generally level (horizontal) to prevent the anchorage connector from sliding down an incline when in use, which could cause serious injury to the user.

#### MAINTENANCE AND STORAGE:

-To clean, wipe with a wet sponge. For more difficult stains, use mild soap. Do not use chemicals or detergents. Rinse off soap with clear water and hang to dry. Do not dry with heat.

-Store the SP SRL, SP SRLD selfretracting fall arrester devices in a cool, dry, clean environment out of direct sunlight. Thoroughly inspect SP SRL, SP SRLD selfretracting fall arrester devices component after extended storage.

**WARNING:** Any repairs to your SP SRL, SP SRLD selfretracting fall arrester devices must be carried out by a manufacturer.

#### INSPECTION BEFORE USE:

SP SRL, SP SRLD selfretracting fall arrester devices be inspected by the user before each use (EN 365:2004). Proper inspection is done with the hands as well as the eyes.

**WARNING:** When inspection reveals defect, damage or inadequate maintenance the SP SRL, SP SRLD selfretracting fall arrester devices must be removed from service to undergo adequate corrective maintenance before return to service. Removal from service may imply that defects of damage will result in retiring or replacing components.

#### PERIODICAL INSPECTION:

Shall be inspected by a manufacturer or a competent person other than user at intervals of no more than one year (EN 365:2004). When the SP SRL, SP SRLD selfretracting fall arrester devices passed an inspection by a suitably qualified person the „remove from service“ area is removed and the SP SRL, SP SRLD selfretracting fall arrester devices is returned to service.

, code of European standards, batch number, length. SP SRL, SP SRLD selfretracting fall arrester devices are manufactured by SKYPRO s.r.o. company, 1.máje 56, 549 01 Nove Mesto nad Metuji, Czech Republic, certified by CE 1019. SP SRL, SP SRLD selfretracting fall arrester devices are manufactured fully according EN 360:2002.

**WARNING:** If labels cannot be fully readed, or are missing, the lanyard must be returned to the manufacturer.

#### LIFE EXPECTANCY:

The life expectancy of fall arrester equipment is a controversial topic. SP SRL, SP SRLD selfretracting fall arrester devices, that are used frequently in industrial conditions, might fail an inspection after one year. SP SRL, SP SRLD selfretracting fall arrester devices, which are dedicated to a single user, that is well maintained, will have a longer life expectancy. The optimal lifetime expectancy for SKYPRO SP SRL, SP SRLD selfretracting fall arrester devices recommended by the manufacturer is 10 years.